

# Measuring Earth's Magnetic Field

using a

Helmholtz Tangent  
Galvanometer



# Items Required:

- Helmholtz Coil. Make one here: <http://tinyurl.com/pes6tzip>
- Benchtop Power Supply
- Connecting Wires
- Field Compass
- Multimeter (Amps Setting)







If you don't have a benchtop PSU,  
you can substitute with a DC PSU  
and Rheostat.




**IMPORTANT:**

Do not exceed the current rating of  
your Helmholtz coil and power supply



# Magnetic Components



- There are a number of metrics for the Earth's Magnetic Field. We're interested in the Horizontal Magnetic Component, also known as "H" and is where a compass points when held on a level plane.
- More information on the various components:  
[http://www.geomag.nrcan.gc.ca/mag\\_fld/comp-en.php](http://www.geomag.nrcan.gc.ca/mag_fld/comp-en.php)



# Find A Magnetically Clean Location

- Use the compass to find a good location
- Move the compass around the location to detect sources of magnetism (ferrous metal objects, magnets, electronics etc.) and avoid them
- Find somewhere the compass points to Magnetic North for a few feet in all directions



# Connect Coil


- Connect the benchtop power supply via an Ammeter to the coil
- If using a regular power supply, connect via an Ammeter and a Rheostat, make sure that the Rheostat is set for minimum current



# Place Compass In Coils and Orientate North

- Ensure PSU is off
- Place the compass in the magnetically uniform cylinder inside the coil
- Orientate the coil so that Magnetic North is parallel with the plane of the wire in the coils
- This will mean that the cylinder through the coils will be lying East/West






Helmholtz Coil Configuration Statistics:  
AWG: 30  
Coil Diameter: 21cm  
Coil Turns: 3  
25649.224 nT / 0.25649 Gauss per amp  
25.64922 nT per mA  
Wire length per coil: 1.983m  
Combined resistance of both coils: 0.001342Ohms  
Voltage required to drive coil: 0.0002698Volts @ 0.201Amps  
Maximum magnetic coil capacity: 5155.494nT for the provided gauge  
Usable Volume (Cylinder): 105Length(mm) x 70Diameter(mm)



# Some Theory - Tangent Law



The Tangent Law Of Magnetism states, when you have a magnet in one direction and you apply a magnet at 90 deg, the resulting field is related by the tangent:

$$B = Bh \times \tan(\theta)$$



# Some Theory - Tangent Law

Because  $\tan(45) = 1.0$ , if current is applied to the Helmholtz coil until the compass needle deflects from Magnetic North by 45 degrees, then  $B = B_h$ .


At this point the magnitude of the field in the Helmholtz coil is equal to the field of Magnetic North.



# Deflect Needle To 45 Degrees

- Increase current in the Helmholtz Coil until the needle deflects 45 degrees
- Note the current (Current I)






Helmholtz Coil Configuration Statistics:  
AWG: 30  
Coil Diameter: 21cm  
Coil Turns: 3  
25649.224 nT / 0.25649 Gauss per amp  
25.64922 nT per mA  
Wire length per coil: 1.983m  
Combined resistance of both coils: 0.001342Ohms  
Voltage required to drive coil: 0.0002698Volts @ 0.201Amps  
Maximum magnetic coil capacity: 5155.494nT for the provided gauge  
Usable Volume (Cylinder): 105Length(mm) x 70Diameter(mm)



# Deflect Needle To -45 Degrees

- Reverse the current in the coil so that the needle deflects in the opposite direction
- Increase current in the Helmholtz Coil until the needle deflects -45 degrees
- Note the current (Current 2)







# Average Current Readings

- We take 2 current measurements in the previous steps to reduce inaccuracy in our alignment
- Average the 2 current measurement, let's call this  $I$  (current mA)



# Determine Coil Strength

- Figure out the nanoTeslas (nT) per mA for your coil. If you're using my coil designer, then OpenScad provided that figure for you, otherwise:
- $\text{nT Per mA (S)} = (899.17629 * N) / R$  where:
  - $N$  = Number of turns on one coil
  - $R$  = Radius in millimeters



# Calculate Magnetic Earth Strength

- Using “S” (nT per mA) and “I” (average current of the Helmholtz Coil in mA), we have:
- Horizontal Magnetic Component in nT (B<sub>h</sub>) = S \* I



# Comparing Bh To Your Location

- Option 1: <http://www.ngdc.noaa.gov/geomag-web/#igrfwmm>  
Enter Latitude/Longitude and elevation. “Horizontal Intensity” is the Bh
- Option 2: <http://geomag.nrcan.gc.ca/calc/mfcal-en.php>  
Enter Latitude/Longitude. “H(nT)” is the Bh



# Music

Demain je change de vie - INSTRUMENTAL VERSION

Lohstana David

Jamendo



License:  
Creative Commons  
CC-BY-SA